






Sakura Kitchen Range Hood Parts List
(Please reference Code number for parts enquiry)

20170101

U Series Style (Code U)	
Code U	Description
U1a	Aluminum Filter (6 pieces per pack) 
U2a	Front Oil Collector 
U3a	Rear Oil Collector (same as R767) 
U4a	Lamp Cover (Oval) 
U4b	Lamp Cover (Round) Old style of U series 
U5a	Oil Tube 
U6a	Nose Cap (Motor Hub Nose) 
U7a	Capacitor 
U8a	3D Vane Guard 
U9a	Lamp Socket / Holder 

Sakura Kitchen Range Hood Parts List
(Please reference Code number for parts enquiry)











20170101

U Series Style (Code U)	
Code U	Description
U10a	Oil Disc for U series (New design with square end to replace old design) 
U11a	Gasket (Spacer Ring) for U series 
U12a	Heat Element Strip for U Heat series 
U13a	PC Board for U Heat series 
U14a	Motor (Left) for U2II & U2II(H) 
U14b	Motor (Right) for U2II & U2II(H) 
U14c	Motor (Left) for U3H 
U14d	Motor (Right) for U3H 
U15a	Fan (Left) for U Heat series 
U15b	Fan (Right) for U Heat series 

Sakura Kitchen Range Hood Parts List







(Please reference Code number for parts enquiry)

20170101

U Series Style (Code U)	
Code U	Description
U16a	Motor Switch (Left) - White (For Old style of U series. Horizontal replaced by Rectangular) 
U16b	Motor Switch (Left) - Grey (For Old style of U series. Horizontal replaced by Rectangular) 
U16c	Motor Switch (Left) - Black (For Old style of U series. Horizontal replaced by Rectangular) 
U16d	Motor Switch (Right) - White (For Old style of U series. Horizontal replaced by Rectangular) 
U16e	Motor Switch (Right) - Grey (For Old style of U series. Horizontal replaced by Rectangular) 
U16f	Motor Switch (Right) - Black (For Old style of U series. Horizontal replaced by Rectangular) 
U16g	Motor Switch - Black for U2 H 
U16h	Motor Switch - Black for U3 H 
U17a	Heat Switch - Black for U2 H 
U17b	Heat Switch - Black for U3 H 

Sakura Kitchen Range Hood Parts List
(Please reference Code number for parts enquiry)

20170101

U Series Style (Code U)	
Code U	Description
U18a	Lamp Switch Rect 3 pin - Black for U2 H 
U18b	Lamp Switch Round - Black for U3 H 
U19a	Soot Shade 30" - Black 
U19b	Soot Shade 30" - White 
U20a	Screw for Vane Guard 
U20b	Screw for Lamp Cover 
U20c	Screw for Supporting Board 